



Dunlop offers an unrivalled range of top quality ceramic tile fixing products. Using the finest raw materials, our products guarantee the outstanding performance demanded by today's market. With easy-to-follow instructions and illustrations, tiling has never been so simple.

Stockist:

Dunlop is a trademark of Ansell Limited and is used under license by Ardex in Australia and New Zealand

ARDEX Australia Pty Ltd 26 Prince William Drive Seven Hills NSW 2147
 Toll Free Technical Service: 1800 222 841 (Aust) 0800 224 070 (NZ)
 Website: www.dunlopdij.com

THE RIGHT CHOICE FOR TILING bathrooms

Get it right first time with Dunlop.

The area most commonly tiled in the home is the bathroom - hygienic and easy to clean, a tiled surface is ideal in this area. Choosing the right adhesive and grout is vital too. Inside this leaflet you will find a helpful illustrated guide. Here are the basics:

- Tiling onto render, fibre cement sheet or plasterboard walls

Dry areas

Dunlop Wall Tile Adhesive
 and Dunlop Coloured Grout
 or Dunlop Ultrawhite Wall Grout

Shower and bath areas:

Dunlop Wall & Floor Tile Adhesive
 and Dunlop Coloured Grout
 or Dunlop Ultrawhite Wall Grout

- Tiling onto existing ceramic tiles:

Dunlop Floor Tile Adhesive (floors)
 or Dunlop Wall & Floor Tile Adhesive (walls & floors)
 or Dunlop Tile-All
 and Dunlop Coloured Grout
 or Dunlop Ultrawhite Wall Grout

THE RIGHT CHOICE FOR TILING

Walls should be flat, clean, dry and in a firm, sound condition. Note that typical background surfaces, such as plaster or plasterboard are water sensitive. If the plaster has a dusty appearance, wipe it down with a damp cloth and prime with **Dunlop Primer and Additive**. Emulsion painted walls should be deeply scored prior to tiling. Use **Dunlop Wall Tile Adhesive** in dry areas.



Remember to use **Dunlop Coloured Silicone** in corners and junctions with other backgrounds, for example baths, basins and vanity tops as shown by the yellow key. (Note: Do not use Dunlop Coloured Silicone over waterproofing membranes, use a neutral cure silicone instead).

In shower and bath areas, ensure tiles are fixed in a solid bed of adhesive. Use **Dunlop Wall and Floor Tile Adhesive**.



In wet areas use a waterproof grout such as **Dunlop Coloured Grout** mixed with **Dunlop Primer & Additive**.



Ensure adhesive and grout is thoroughly dry before using the newly tiled area.

Remember, timber bath sides are prone to movement. Use **Dunlop Wall & Floor Tile Adhesive** and **Dunlop Coloured Grout** mixed with **Dunlop Primer & Additive**.



CHECKLIST

- Tiles
- Primer
- Adhesive
- Grout
- Silicone Sealant
- Tile Trim

TOOLS AND EQUIPMENT

- Wall Tile Spacers (2 or 3mm)
- Spirit Level
- Tile Cutter
- Tile Nippers
- Tile Saw
- Tile File
- Notched Trowel
- Grout Squeegee/Float
- Sponge
- Sealant Gun
- Plastic Gloves

Important: Full instructions for surface preparation and product usage appear on all Dunlop packaging. To make the job easy and worry-free, please ensure you follow them.

Ceramic tiles are ideal for bathroom floors; waterproof, hygienic and easy to clean they are the perfect permanent solution. Download our floors leaflet for more information.

For more information on tiling in shower areas download our Showers leaflet.